


RÄJÄYTYSKUVA XCN65



OSALISTA XCN65

ITEM	ERP	DESCRIPTION	QYT	ITEM	ERP	DESCRIPTION	QYT
1	4010220252	Screw	1	53	2010270417	Stopped Hook B	1
2	4010270557	Bushing	1	54	2010150037	Latch	1
3	4010030016	Exhaust Cover	1	55	4010270014	Washer	3
4	4010070009	Seal	1	56	4010140478	Block	1
5	4010160135	Muffler	1	57	4010220003	Screw	2
6	4010220102	Screw	6	58	4010190026	O-ring 20. 3x2.5	1
7	4010220164	Spring Washer	8	59	4010190025	O-ring 20. 3x1.5	1
8	2010020245	Cylinder Cap	1	60	4010130132	Valve Guide	1
9	4010070053	Gasket	1	61	4010190009	O-ring 9.5x1.9	1
10	4010160160	Spring	1	62	4010190010	O-ring 10. 3x1.9	1
11	4010190138	O-ring 42. 8x2. 65	1	63	2010130133	Trigger Valve Seat	1
12	2010130096	Valve	1	64	4010190015	O-ring 12. 8x1.9	1
13	4010190140	O-ring 58. 7x3. 5	1	65	4010160075	Spring	1
14	4010130042	Valve Seat	1	66	4010190001	O-ring 5.5x1.5	2
15	4010270289	Collar	1	67	2010130129	Trigger Valve Stem	1
16	4010270290	Cylinder Seal	1	68	4010220349	Spring Pin 3x26	1
17	4010190139	O-ring 45. 3x4	1	69	4010130137	Trigger Valve Guide	1
18	2010050178	Piston Assembly	1	70	4010160284	Trigger Spring	1
19	4010040085	Cylinder	1	71	4010270208	Spring pin	1
20	4010190050	O-ring 52. 4x2. 5	2	72	4010220154	Lock washer	1
21	4010270552	Restrictive Plate	1	73	1019991002	Trigger Assembly	1
22	4010190141	O-ring 81. 8x2. 65	1	74	4010220190	Steel Ball	2
23	4010060036	Bumper	1	75	4010160033	Spring	2
24	2010011283	Body	1	76	2010270668	Rotating Shaft Pin	1
25	4010190051	O-ring 53x1.5	1	77	1019991003	Handwheel Assembly	1
26	4010220186	Nut	2	78	4010160148	Spring	1
27	4010220174	Washer	1	79	4010220411	Washer	1
28	4010190116	O-ring 7. 5x1. 5	1	80	4010190013	O-ring 12. 3x1.9	1
29	4010270292	Protector	1	81	4010050061	Piston	1
30	4010220092	Screw	1	82	4010210063	Feed Hook Pin	1
31	4010220163	Spring Washer	1	83	4010190061	O-ring 24. 3x2.8	1
32	4010270471	Restrictive Guide	1	84	4010160072	Spring	1
33	2010080173	Nose	1	85	4010060040	Piston Bumper	1
34	4010220464	Screw	2	86	2010270125	Cover	1
35	4010270014	Washer	1	87	4010220147	Locking Washer 28	1
36	4010210089	Pin	1	88	4010160120	Spring	1
37	2010170149	Safe Bracket	1	89	2010270419	Feed Hook	1
38	4010270293	Safe Sleeve	1	90	4010220003	Screw	3
39	4010270908	Safe Guide	1	91	4010270644	Spacer	1
40	4010220354	Spring Pin 3x28	2	92	4010210072	Pin	1
41	4010160161	Spring	1	93	4010140245	Lower Nail Housing	1
42	2010170150	Bracket	1	94	4010270306	Adjusting Stem	1
43	4010270423	Adjusting Stem	1	95	4010270498	Adjuster Bushing	1
44	4010190003	O-ring 6. 4x1. 5	1	96	4010140355	Adjuster Plate	1
45	4010270295	Handwheel	1	97	4010270260	Adjuster Nut	1
46	4010270296	Adjusting Seat	1	98	4010210014	Spring Pin 2. 5x17	1
47	4010220100	Screw	1	99	4010140246	Upper Nail Houshing	1
48	4010210084	Washer	1	100	4010270232	Soft Grip Sleeve	1
49	4010210017	Spring Pin 2. 5x20	1	101	4010190043	O-ring 48. 8x2.5	1
50	4010210079	Stopped Hook Pin	1	102	2010110030	End Cap	1
51	2010270416	Stopped Hook A	1	103	4010120005	Air Plug	1
52	4010160162	Spring	1				

H&H Tuonti Oy, Lanttikatu 1, 02770 Espoo, puh. (09) 525 9030, www.hhtuonti.fi